



# MDT

## USER MANUAL

Version 10.08.25

# CKYE-POD RUBBER FEET

**HAVE QUESTIONS OR  
NEED ADDITIONAL SUPPORT?**

---

**support@mdttac.com**  
**+1 (604) 393-0800**

**TOOL REQUIRED**

3/32" Pin Punch

**WANT TO LEARN MORE?  
CHECK OUT OUR INSTALL VIDEO**



---

Copyright © MDT Sporting Goods Ltd.

1. Remove current feet from your bipod.
  - A. **Note:** If installing on a Ckye-Pod you can remove your current ones by inserting a pin punch into the hole on the side of foot, tugging down to release.
  
2. Push down on the pin in the Ckye-Pod rubber feet and slide the feet into the tube of the bipod leg ensuring pin aligns and pops out the hole. (May need to give the bottom of the foot a good tap on top of the bench to seat)
  - A. **Note:** For easier installation, make sure to add some lube to the O Ring.